

Energizer®

MULTI-PURPOSE HANDSFREE LIGHT

The **Energizer Multi-Purpose Rechargeable Handsfree Light** offers powerful brightness in a compact, innovative design. Easily attach it to clothing or a cap with the versatile clip, secure it to metal surfaces with the magnet, or use the included head-strap for various hands-free applications. Choose from six modes—including area, directional, and direct light precisely where you need it using the pivoting feature. Activate the optional motion sensor mode to switch between directional modes without pushing a button. Built to last, this slim and durable light is IPX4 water-resistant and features a shatterproof lens, making it perfect for outdoor adventures, work tasks, or home use.

6
MODES



PRESS TO
CHANGE
MODE



AREA
LIGHT

HANDSFREE
DESIGN WITH
MOTION SENSOR

DIRECTIONAL /
SPOT LIGHT



INDICATOR LIGHT
RED FOR CHARGING
BLUE FOR MOTION SENSOR



MAGNET



HEAD STRAP
ATTACHMENT



PIVOTING
FEATURE

CLIP



OPERATING INSTRUCTIONS

HOW TO USE:

Press on/off button to turn on.

- Press 1 time for spot high.
- Press 2 times for spot low.
- Press 3 times for white area.
- Press 4 times for white flashing area.
- Press 5 times for red area.
- Press 6 times for green area.

OFF After 2 seconds in a mode, next press will be off.

TO USE MOTION SENSOR MODE:

Motion sensor control only works on spot modes.

Press and hold the on/off button for 3 seconds at any time to activate the motion sensor function. Indicator light will turn blue, showing motion sensor is on.

The waving hand or object in front of light to start sequence of modes.
(High → Low → Off)

The best effective distance is no less than 5cm (2 in.) or more than 12cm (4 in.).

Quick press to turn off motion sensor mode.

HOW TO CHARGE:

Rechargeable battery is not user replaceable.

To charge use included USB cord and plug light into any USB charging port.

Lights may be used while charging, but charging time will be increased and brightness may be reduced.

For best charging performance, charge with light turned off.

Charging Indicator light is located near charging port.

DESIGN FEATURES:

Wearable with clip or attach to head strap (included) / hat / vest.

Magnet for additional hands-free use option.

Pivoting feature to direct light where needed.

