

# Energizer®

## HYBRID HEADLAMP 2000XT-H


The Energizer 2000XT-H Hybrid Metal Headlamp provides extreme brightness, shining up to 2000 lumens. Multiple modes allow a handsfree solution for on the job, emergencies or outdoor activities in any weather conditions or time of day. This light features a charging indicator and a low battery indicator, keeping your mind at ease. Built with versatile power options, this hybrid headlamp can be powered by a rechargeable or CR123 batteries. Take the light off the strap to be used as a handheld flashlight or use the magnet attachment for an additional hands-free use option. Built to last, the durable metal headlamp is waterproof, dustproof with a shatterproof lens.



PRESS TO CHANGE MODE



### BATTERY REPLACEMENT




RECHARGEABLE BATTERY

-OR-

PRIMARY BATTERIES

LOW BATTERY INDICATOR

### RECHARGEABLE BATTERY




BATTERY CHARGING INDICATOR

TWIST SIDE WITH BATTERY ICON TO ACCESS BATTERIES

TWIST SIDE WITH USB ICON TO ACCESS CHARGING PORT

RECHARGEABLE BATTERY CHARGE LEVEL INDICATOR



TOP STRAP

MAIN STRAP

DETACHABLE HANDHELD FLASHLIGHT OPTION

PIVOTING FEATURE

MAGNET

# OPERATING INSTRUCTIONS

## HOW TO USE:

Press on/off button to turn on.

Press 1 time for high.

Press 2 times for medium.

Press 3 times for low.

**OFF** Press 4 times for off.

Press 2 times very quickly (double press) in any mode for red.

Next press will be green.

**OFF** Third press will be off.

Press & hold 2 sec at any time (including off) for boost.

After 40 seconds, the light will return to high.

There is a 40 second lock out until boost can be used again.



**CAUTION:** Potential burn hazard.

Avoid contact with area with "HOT" symbol while in use.

## HOW TO POWER:

### PRIMARY OR RECHARGEABLE BATTERIES

#### TO REPLACE BATTERIES:

- Unscrew and remove end cap with the battery icon to access batteries.
- Follow diagram on light for battery orientation.

#### LOW BATTERY INDICATOR:

- While light is being used, a colored LED will flash 3 times when battery is low.
- Recharge battery or replace primary batteries.

### RECHARGEABLE BATTERY

#### CHARGING BATTERY OUTSIDE THE LIGHT:

- Unscrew end cap with the battery icon to access and remove rechargeable battery.
- To charge, use included USB cord and plug battery into any USB charging port.
- Charging the battery outside the light allows user to operate light on primary power while rechargeable battery recharges.

#### RECHARGEABLE BATTERY CHARGE LEVEL INDICATOR:

- Charge Indicator is located on top of rechargeable battery.
- Individual LEDs will light up when the battery reaches the 25%, 50%, 75%, and 100% charged.

#### CHARGING BATTERY INSIDE THE LIGHT:

- Unscrew the end cap with the USB icon to reveal the charge port.
- To charge use included USB cord and plug light into any USB charging port.

#### BATTERY CHARGING INDICATOR:

- Charge Indicator is located by the USB port and will illuminate when the USB charging has started.

● Red = Charging

● Green = Charging complete

## DESIGN FEATURES:

- Comfortable head-strap with optional top strap for additional support.

#### TO REMOVE TOP STRAP

1. Unhook the main strap from under the slider.
2. Top strap will slide off main strap.

- Pivoting feature to direct light where needed.

- Detachable to be used as a handheld flashlight.

- Magnet for additional hands-free use option.

