

# Energizer®

## RECHARGEABLE LANTERN

Never get caught in the dark with the **Energizer Digital Power Indicator Lantern!** The easy-to-use power indicator display gives consumers comfort, confidence & flexibility as they know how much run time they have left AND can adjust the brightness to maximize the run time!

DIMMABLE



### DIGITAL DISPLAY

BATTERY POWER INDICATOR



ADJUST THE BRIGHTNESS TO EXTEND RUN TIME



### CHARGES OTHER DEVICES


CHARGE WITH INCLUDED USB



### CABLE STORAGE

### HANGER HOOK

### ADJUSTABLE HANDLE



## OPERATING INSTRUCTIONS

### HOW TO USE:

- As soon as the power button is pressed, night light mode will turn on.
- Press again to turn on white area light.
- When white area light is on, press and hold longer than 2 seconds to increase or decrease brightness. Light will flash at brightest and dimmest. Release button to set light level.

### DIGITAL DISPLAY

#### RUNTIME INDICATOR

- The runtime indicator will appear first.
- This shows how many hours and minutes of runtime remain on the current brightness level selected.
- A lower brightness may be selected to extend runtime.

#### BATTERY POWER INDICATOR

- The battery power indicator will appear ~5 seconds after the runtime indicator appears on desired brightness level.
- This shows the battery percentage remaining.
- A lower brightness may be selected to extend battery life.
- Both indicators will update as you press and hold to select brightness.
- After both indicators have appeared on desired brightness, the screen will go dark.
- Once the runtime has been met, the light will enter a dimmed mode. Display will indicate this with a dimmed orange screen displaying a low battery. Once battery is fully depleted the dimmed display will flash red every minute. Recharging is required.

### HOW TO CHARGE:

- Rechargeable battery is not user replaceable.
- To charge use included USB cord and plug light into any USB charging port.
- Light may be used while charging, performance may vary.
- Light may be used to charge another USB device. Light will operate in nightlight or lowest white brightness setting during charge out.
- Light cannot be recharging and charge out at the same time. Recharging the light will take priority to charging devices.

### BATTERY CHARGE INDICATOR

- Rechargeable Lantern display will show battery status. Press on/off button for 1 second to turn on display at any time to see battery charge status.

### ADJUSTABLE HANDLE:

- Adjustable Handle for easy carrying or loop onto bag.

### HANGER HOOK:

- Flip up attachment at the bottom allows for hanging from a hook overhead.

### CABLE STORAGE:

- Twist flipped up attachment to the left to access cable storage.

